

## Easy Freestanding Skateboard Rack

### Materials:

2 4-foot pieces of 1" X 8"

3 hinges (no longer than 1-3/4" long)

Drill (if rounded ends are desired)

Sand paper

Felt with adhesive backing

Jig saw



It may be easier to clamp the two boards together for drilling and jigsaw work. This will help in lining up the pieces.

### Directions:

1. Cut board into two 2" lengths, sand rough edges.
2. Layout board to the dimensions below.
3. Clamp boards together.
4. Using a 1" diameter hole saw, drill through both boards to create holes as noted on diagram.
5. Using jigsaw or other handheld saw, connect to holes.
6. Sand rough edges smooth.
7. Lay pieces together so that slots match. Attach hinges to upper, middle and lower seam.
8. Cut strips of felt to line the edge of board to prevent scratching skateboard.
9. Remove adhesive and attach to edges.
10. Enjoy!

Layout:

